

## Cleaning Combi water level probes (error code #4)



### **CLEANING COMBI ELECTRODES (PROBES)**

Remove cover over steam chamber to view water level electrodes.



Carefully slide wire connectors off electrodes Pull electrode up and out. Immerse probe in mild decalcifying agent (i.e. CLR) for a period of time.

Wipe clean and rinse thoroughly.

Re-insert electrode back into position.

Re-connect electrodes according to corresponding color.